

Accessories and Spare Parts Food Waste Disposer



## **AIR SWITCH BUTTON COVERS**

Customise your kitchen benchtop with an InSinkErator Air Switch Button for ease of access and a stylish finish. For use with models 56, 66, EVO100, EVO200 or any model with an Air Switch Kit.



Chrome Finish

IP73274K









**Biscuit Finish** IP73274B



IP73274







**Glossy Black Finish** 

IP73274A







in sink erator

Matte Black Finish IP73274C

French Gold Finish IP73274G

## SINK FLANGES AND STOPPERS

Your food waste disposer is tucked away out of sight under your sink. But, that doesn't mean that it can't make a visual statement in your kitchen. Select a custom sink flange & stopper from one of the many available finishes to give your sink a designer's touch & make a statement about your style.



## **SPARE PARTS**

InSinkErator<sup>®</sup> Spare Parts use an easy to assemble, do-it-yourself style collection for your kitchen to maintain and upkeep your InSinkErator<sup>®</sup>.

Installation Kit For models 45, 46, 55, 56, 65, 66 Product Code: IP75226B



Installation Kit For models EV0100 & EV0200 Product Code: IP75268

Tail Pipe White For models E20, 45, 46, 55, 56, 65, 66 Product Code: IP73238



Tail Pipe Black For models EV0100, EV0200 Product Code: IP75436







Removable Baffle - Antimicrobial Baffle For models 56, 66, EV0100, EV0200 Product Code: IP74653D





Mounting Gasket For models 56, 66, EV0100, EV0200 Product Code: IP74054



Sink Flange Gasket Fits All InSinkErator® Models ProductCode: IP8763



- Standard Mounting Gasket For models E20, 45, 45+, 46, 55, 55+, 65

Mounting Gasket



Product Code: IP5029



Tail Pipe Gasket Fits Models: E20, 45, 46, 55, 56, 65, 66 ProductCode: IP1470

Stopper - Plastic ProductCode: IP4310



Jam-Buster Wrench ProductCode: IP8305D









Air Switch Button For use with models with existing air switch button. Product Code: IP75430B

ALL THESE PRODUCTS ARE AVAILABLE AT WWW.INSINKERATOR.CO.NZ